

Spare Parts List

CK / CKT Electric Heaters

No.	Part No.	Description
1	145513	Front panel
2	137343	Air outlet grill, black
3	164746	Side panel, left, white plastic
4	164735	Side panel, right, white plastic
5	136058	Side panel insert, CK only
6	137419	Thermostat
7	139319	Thermostat knob
8	164758	Fan 120 V, complete unit
8	164751	Fan 208 / 240 V, complete unit
9	164759	Heating element, 120 V, 1500 W
9	164752	Heating element, 208 - 240 V, 1500 / 2000 W
10	147952	Air duct, galvanized sheet metal
11	164750	Back wall, galvanized sheet metal
12	033448	Wall mounting bracket
13	136996	Wall angle bracket

CKT Electric Heaters

No.	Part No.	Description
	290683	Side panel, right
	136059	Side panel insert
	139318	Timer switch knob
	250373	Timer switch

Spare Parts Diagram

