

Model/Modelo/Modèle
191LF
Series/Series/Seria

▲ Specify Finish
 Précisez la Finition
 Especifique el acabado

RP64393
 Aerator & Wrench
 Aérateur et Clé
 Aireador y Llave

RP78491
 Aerator - 1.5 GPM (5.7 L/min)
 Aérateur - 1,5 gal/min (5,7 L/min)
 Aireador - 1,5 gpm (5,7 L/min)

RP80832
 Aerator - 1.0 GPM (3.8 L/min)
 Aérateur - 1,0 gal/min (3,8 L/min)
 Aireador - 1,0 gpm (3,8 L/min)

RP64394
 Spout Ring Assembly
 Montage de l'anneau
 du col du robinet
 Conjunto de aro para
 el pico

RP64391
 Cartridge & Retainer Ring
 Cartouche et anneau de rétention
 Cartucho y anillo de retención

RP64395▲
 Base & Gasket
 Base et joint
 Base y junta

RP64380▲
 Cap
 Embase
 Tapa

RP47300
 Hoses
 Boyaux
 Mangueras

RP76351▲
 Stick Handle Assembly
 Montage de la manette de bâton
 Conjunto de la manija de palo

RP64397
 Mounting Hardware
 Pièces de montage
 Herraje de instalación

OPTIONAL

RP64396▲
 Gasket & Base Plate
 Joint plat et plaque de finition
 Junta y placa de base

