

# SIZING CHART

## TO FIND THE PERFECT DISTINK™

### ALCOVE SHOWER DOOR





Determine the space needed for your alcove door.

Width: A = \_\_\_\_\_

Width: B = \_\_\_\_\_

**IMPORTANT: Use the larger width.**



Width: A or B				
from 813 to 965 mm (from 32" to 38")	> 965 to 1118 mm (> 38" to 44")	> 1118 to 1270 mm (> 44" to 50")	> 1270 to 1422 mm (> 50" to 56")	> 1422 to 1575 mm (> 56 to 62")
DR1738	DR1739	DR1740	DR1741	DR1742

> = higher than

Eg.: if your larger width is more than: **38 1/2"** the shower door model that suit you is the: **DR1739**