



Technical Bulletin 154 - External Recirculation Pump Wire Harness For SENSEI™ Models

Purpose: When installing an external recirculation pump on a SENSEI™ tankless water heater (non-RUR models), the external pump wire harness (part number 105000250) must be purchased separately.

SENSEI™ tankless water heater models (non-RUR) include:

- RU199i/e
- RU180i/e
- RU160i/e
- RU130i/e
- CU199i/e
- CU160i/e

For complete instructions on installing and wiring an external recirculation pump on a SENSEI™ tankless water heater, refer to the “Rinnai Tankless Water Heater Installation and Operation Manual.”

