
Ashbee[™] Pressure Balance Tub/Shower Valve Trim

AMERICAN STANDARD

Cross Handle Model D35101640 Lever Handle Model D35101600


To be used with D35000600.191 Rough Valve for Pressure Balanced Bath/


Thank you for selecting DXV by American Standard. To ensure that your installation proceeds smoothly, please read these instructions carefully before you begin.



RECOMMENDED TOOLS AND MATERIALS

Most of the procedures require the use of common tools and materials, which are available from hardware and plumbing supply stores. It is essential that the tools and materials be on hand before work is begun.





In the United States:

DXV by American Standard One Centennial Avenue Piscataway, New Jersey 08855 Attention: Director of Customer Care

For residents of the United States, warranty information may also be obtained by calling the following toll free number: (800) 227-2734 www.DXV.com

In Canada:

DXV by American Standard 5900 Avebury Road Mississauga, Ontario L5R 3M3 Canada

Toll Free: 1-800-387-0369 Local: 905-306-1093 Fax: 1-800-395-1498 www.DXV.ca

In Mexico:

DXV by American Standard Via Morelos 330 Col. Santa Clara Coatitla Ecatepec, Estado de México 55540

Toll Free: 01-800-8391200 www.DXV.mx VE FOR FUTURE USE

S




CAUTION Turn off hot and cold water supplies before beginning.

After finished tiling the wall, remove PLASTER GUARD (1).
Remove two screws that secure the DIVERTER LID (2) and remove Lid. Inspect the inside surface of diverter port.
Diverter port must be free of any dirt. Clean if necessary.

• Install DIVERTER (3) with SCREWS (4) removed from DIVERTER LID (2).

• Operate DIVERTER (3). DIVERTER (3) should slide in and out smoothly.

• Push on DIVERTER COVER (5).



DIVERTER

PORT

2 INSTALL TRIM

CAUTION Turn off hot and cold water supplies before beginning.

• Push CAP (1) onto VALVE CARTRIDGE (2). Secure CAP (1) to VALVE CARTRIDGE (2) with SCREW (3) for LEVER HANDLE only. (Spline in CAP (1) must fully engage spline on cartridge stem).

• Mount ESCUTCHEON HOLDER (16) with gasket and ESCUTCHEON (4) to valve body with SCREWS (5).


• Push the COVER (17) as shown over the CAP (1).

• Thread DIVERTER KNOB (6) onto diverter stem.

2a INSTALL HANDLE (ADJUST HOT LIMIT STOP PRIOR TO HANDLE INSTALLATION, SEE STEP 3)

• FOR CROSS HANDLE: Thread HANDLE BASE (7) onto threads of CAP (1) until seated against it's internal stop. With VALVE in off position align CROSS HANDLE (8) as desired. Install CROSS HANDLE (8) onto VALVE STEM (9) and tighten HANDLE SCREW (10). Insert INDEX (11) into CROSS HANDLE (8).

• LEVER HANDLES: Thread HANDLE BASE (12) onto threads of CAP (1) until seated against it's internal stop. Install FRICTION WASHER (15) onto base of LEVER HANDLE (13). Align LEVER HANDLE (13) and tighten set screw with HEX WRENCH (14) supplied with faucet to secure handle.




10

LEVER HANDLES

ADJUST HOT LIMIT STOP (MUST BE DONE PRIOR TO TRIM INSTALLATION)

By restricting HANDLE rotation and limiting the amount of hot water allowed to mix with the cold, the HOT LIMIT SAFETY STOP (1) reduces risk of accidental scalding. To set the maximum hot water temperature of your faucet, all you need to do is adjust the setting on the HOT LIMIT SAFETY STOP (1).

• Turn CARTRIDGE STEM (2) to the OFF position (coldest setting) before making adjustment to HOT LIMIT STOP (1). Use a flat blade screwdriver to pry free the HOT LIMIT SAFETY STOP (1). Pull forward and rotate counterclockwise one number to limit hot water temperature. Use ARROW (3) on CARTRIDGE (4) and NUMBERS (5) on HOT LIMIT STOP (1) for indication.





Ashbee™

Pressure Balanced Tub/Shower Valve Trim

MODEL NUMBERS

Cross Handle

D35101640

Lever Handle

D35101600

Replace the "YYY" with appropriate finish code

POLISHED CHROME	100
BRUSHED NICKEL	144
PLATINUM NICKEL	150

